

Installation Instructions

安裝說明書

RR. SUBFRAME FRONT BRACE

後樑前拉桿

#Q0273

Application 適用車型

MAZDA CX-5 2012-2016 FWD
MAZDA CX-9 2017-

Components 內含配件

- ① Brace-RH 結構桿桿身-右.....1pcs
- ② Brace-LH 結構桿桿身-左.....1pcs

Caution 注意事項

- Installation is recommended to be performed by licensed mechanics with necessary tools to ensure safety. Incorrect installation may cause injury, damage to the product or vehicle. 安裝建議由合格的技師及工具執行以確保安全。安裝錯誤可能對人員、產品及車輛造成傷害。
- Note the routing of wires and cables before installation, or please refer to factory manual. 安裝前請事先記下線路的安裝路徑及位置以維持原廠配置。有疑問時請參考原廠手冊。
- Tighten bolts and nuts firmly by using handtools, and with specified torque if mentioned. 安裝過程請使用手動工具確實鎖緊螺帽及螺絲。如有特別註明請依照說明指示的扭力上鎖。

Instructions 安裝說明

1. Support rear subframe using a jack.
使用千斤頂將後副車架頂住。
2. Remove the rear subframe front mounting bolts.
拆卸後副車架前端固定螺絲。
3. Loosen the rear toe link inner bolts.
鬆開後束角連桿內側螺絲。



4. Install the brace to the subframe.
將結構桿桿身安裝至副車架。
5. Reinstall and tighten the bolts to secure the braces.
完成後鎖上螺絲以固定桿身。

▲ Illustration of installed state 安裝完成示意圖

